

Hempoxies Synthesis Procedures & Chemistry

TRL 1–2 Forward-Looking Research Framework

Status: Theoretical bio-based vitrimer research hypothesis with projected (not validated) performance targets

Version: Based on Hempoxies v.17.2 and Hempoxies 56 frameworks

Author: Marie-Soleil Seshat Landry, Marie Landry's Spy Shop / Landry Industries

I. MATERIAL OVERVIEW

Core System Components

Primary Resin Matrix:

- Epoxidized Hempseed Oil (EHSO) — bio-renewable epoxy backbone
- Epoxy:Carboxyl stoichiometry: 1:0.8 (fixed-datum ratio)

Crosslinker:

- Citric Acid — polycarboxylic acid, creates dynamic ester bonds via transesterification

Catalyst:

- Zinc Acetate ($\text{Zn}(\text{OAc})_2$) — 1 wt% loading, enables zinc-catalyzed transesterification

Reactive Diluent:

- Furfuryl Glycidyl Ether (FGE) — 8.9 wt% loading, reduces viscosity, enables processing

Processing Aid (Hempoxies 56):

- Anhydrous Ethanol — improves catalyst dispersion and prevents agglomeration

Reinforcement (Hierarchical Portfolio):

- Polyacrylonitrile-based Carbon Fiber (PAN-CF)
- Native hemp bast fiber

- Biochar (thermally derived from hemp biomass)
 - Activated carbon
 - Carbonized hemp fiber
 - Graphene nanosheets (optional)
 - MXenes (optional advanced fillers)
-

II. STAGE 1: EPOXIDATION OF HEMP SEED OIL

Background Chemistry

Hemp seed oil contains unsaturated fatty acids (primarily linoleic and α -linolenic acid) with C=C double bonds. Epoxidation converts these olefinic bonds into oxirane rings (three-membered epoxide rings), creating reactive epoxy groups for subsequent polymer network formation.

Procedure: In Situ Performic Acid Epoxidation

Materials Required:

- Hemp seed oil (high-oleic cultivar preferred for thermal stability)
- Hydrogen peroxide (H_2O_2), 30–50% aqueous solution
- Formic acid (HCOOH), reagent grade
- Ion exchange resin catalyst (Amberlite IR-120H or equivalent acidic resin)
- Sodium hydroxide (NaOH) for neutralization
- Sodium carbonate (Na_2CO_3) for workup
- Distilled water

Safety Note:

Performic acid is a strong oxidizer. Work in a fume hood with appropriate PPE (chemical gloves, safety glasses, lab coat).

Stoichiometry (Typical):

For 100 g hemp seed oil:

- H_2O_2 : ~35–40 g (1.0–1.2 mol H_2O_2 per mole unsaturation)
- Formic acid: ~30–35 g (generates performic acid in situ)
- Amberlite IR-120H: ~5–8 g (5–8 wt% of oil mass)

Step-by-Step Procedure:

1. Reactor Setup:

- Use a round-bottom flask (3–5 L capacity) equipped with overhead stirrer, thermometer, addition funnel, and condenser
- Heat with controlled water bath or oil bath
- Maintain inert atmosphere (argon/nitrogen flow or positive pressure) throughout

2. Catalyst Activation:

- Activate Amberlite resin by suspending in distilled water (1:10 w/v) for 30 minutes
- Drain water and air-dry on filter paper
- Pre-heat resin to 50–60°C in the reactor before oil addition

3. Oil Introduction:

- Add hemp seed oil (100 g) to the heated reactor with activated resin
- Stir at 200–300 rpm to suspend catalyst

4. Performic Acid Generation:

- In a separate container, slowly mix formic acid with H_2O_2 (typically 1:1 molar ratio)
- Perform this mixture preparation outside the reactor; an exothermic reaction occurs
- Allow mixture to cool to room temperature before addition (typically ~10–15 min)

5. Controlled Addition:

- Using addition funnel, slowly add the performic acid mixture to the oil+catalyst suspension at 50–60°C
- **Critical:** Add dropwise over 2–4 hours (too fast = runaway reaction/foam)
- Maintain temperature between 50–65°C throughout

- Stir continuously

6. Reaction Progression:

- After complete addition, increase temperature to 65–75°C
- Continue stirring for 2–4 hours (reaction completion typically 4–6 hours total)
- Monitor conversion via iodine value titration (target: <2 g I₂/100g, indicating <2% residual unsaturation)

7. Catalyst Removal:

- Cool reaction mixture to <40°C
- Filter through fine filter paper or 0.45 µm syringe filter to remove spent resin
- Collect filtrate (epoxidized hemp seed oil product)

8. Workup & Neutralization:

- Transfer filtrate to separatory funnel
- Add 10% Na₂CO₃ solution (10 mL per 100 g oil) to neutralize excess formic acid
- Shake gently and allow phases to separate (~15 min)
- Remove aqueous layer (lower)
- Repeat Na₂CO₃ wash 2–3 times until aqueous layer is neutral (pH paper)

9. Water Removal:

- Wash organic layer with distilled water (3 × 10 mL per 100 g oil)
- Transfer to separatory funnel, remove aqueous layer each time
- After final aqueous wash, dry over anhydrous Na₂SO₄ (10 g per 100 g oil) for 30 min
- Filter to remove drying agent

10. Final Product:

- EHSO is now a light golden to amber viscous liquid
- Store in amber glass bottles under argon at room temperature (shelf-life ~3–6 months)
- Quantify epoxy content via epoxy titration (target: 4.5–5.5 wt% epoxy oxygen)

Characterization of EHSO:

- **Epoxy Value (wt% oxygen):** Titration with HCl/dioxane
 - **Iodine Value:** <2 g I₂/100g (residual unsaturation)
 - **Acid Value:** <1 mg KOH/g
 - **Viscosity:** ~150–250 mPa·s at 25°C (depending on fatty acid profile)
 - **FT-IR:** Peak at 840–860 cm⁻¹ (epoxide C–O stretch), absence of C=C stretch at 1650 cm⁻¹
 - **¹H NMR:** Characteristic epoxide proton multiplet at 2.8–3.2 ppm
-

III. STAGE 2: VITRIMER MATRIX SYNTHESIS

Covalent Adaptable Network (CAN) Formation

Chemistry Overview

The Hempoxies system forms a dynamic network through:

1. Primary Cross-linking (Esterification):

- Epoxy groups (from EHSO) undergo ring-opening with hydroxyl groups (from citric acid)
- Forms secondary and tertiary hydroxyl groups
- Citric acid's carboxyl groups esterify with these hydroxyl groups
- Creates ester crosslinks

2. Dynamic Bond Exchange (Transesterification):

- At $T > T_v$ (topology freezing temperature, ~150–160°C), ester bonds undergo associative bond exchange
- Catalyzed by Zn(OAc)₂
- Network topology rearranges dynamically, enabling reprocessability and self-healing

Materials Required:

- Epoxidized Hempseed Oil (EHSO) — from Stage 1
- Citric Acid (anhydrous) — reagent grade
- Zinc Acetate Dihydrate ($\text{Zn}(\text{OAc})_2 \cdot 2\text{H}_2\text{O}$) — reagent grade
- Furfuryl Glycidyl Ether (FGE) — commercial epoxy diluent
- Anhydrous Ethanol (or anhydrous methanol) — solvent/processing aid
- Silica molds or mold release spray
- Aluminum foil

Stoichiometry (per 100 g EHSO):

For 1:0.8 epoxy:carboxyl ratio:

Component	Amount	Notes
EHSO	100.0 g	(assuming 5 wt% epoxy oxygen)
Citric Acid	~36–38 g	Three carboxyl groups per molecule; empirically ~36–38 wt% of EHSO
$\text{Zn}(\text{OAc})_2 \cdot 2\text{H}_2\text{O}$	1.0 g	1 wt% catalyst loading
FGE	8.9 g	8.9 wt% reactive diluent
Anhydrous Ethanol	5–10 g	5–10 wt% of total resin mass (Hempoxies 56 enhancement)

Total resin mass: ~150.9–152.9 g

Procedure A: Neat Synthesis (without solvent)

1. Equipment Setup:

- Use sealable glass vessel or stainless steel reaction vessel (autoclave-grade)
- Equipped with magnetic stirring bar, thermometer, and N_2 inlet
- Pre-heat vessel to 80°C
- Purge with dry nitrogen for 5 minutes to remove atmospheric moisture

2. Component Mixing (Order Critical):

- Weigh EHSO (100.0 g) into vessel
- Add FGE (8.9 g) dropwise while stirring (~500 rpm)
- Allow to mix for 2–3 minutes until homogeneous

3. **Catalyst Dissolution:**

- Add anhydrous ethanol (7.5 g, ~7.5 wt%) to vessel with EHSO+FGE blend
- Stir at 60–70°C for 2 minutes
- In separate beaker, dissolve $\text{Zn}(\text{OAc})_2 \cdot 2\text{H}_2\text{O}$ (1.0 g) in minimal anhydrous ethanol (~1–2 mL)
- Stir $\text{Zn}(\text{OAc})_2$ solution briefly (generates a clear to faintly turbid solution)

4. **Zinc Addition & Pre-cure:**

- Add $\text{Zn}(\text{OAc})_2$ ethanol solution to main vessel
- Stir vigorously for 1 minute at 60°C (promotes dispersion)
- **Hempoxies 56 enhancement:** The ethanol phase prevents catalyst agglomeration
- Reduce agitation to ~200 rpm; continue at 60°C for 5 minutes

5. **Citric Acid Integration:**

- Slowly add citric acid (36.5 g) in small portions (~0.5 g increments) while stirring
- **Critical:** Add slowly; citric acid is partially soluble and exothermic reaction occurs
- After each addition, wait ~30 seconds for thermal/mixing equilibration
- Temperature may rise to 65–70°C; control with water bath if needed
- Continue until all citric acid is added (~8–10 minutes for full addition)

6. **Post-addition Mixing:**

- After complete citric acid addition, increase stirring to 500 rpm
- Continue at 60–65°C for 10 minutes
- Mixture becomes increasingly viscous (appearance: light brown, opaque, putty-like consistency)

7. **Degassing (Critical):**

- Heat to 80°C under low vacuum (if available) or nitrogen sparge for 10 minutes
- Purpose: Remove air bubbles trapped during mixing (air pockets degrade final properties)
- Alternative: Centrifuge at 1000 g for 2–3 minutes to settle bubbles

8. Mold Casting:

- Prepare silicone molds or aluminum molds with mold release spray (PTFE spray ideal)
- Pour resin into molds at 80°C (temp must be maintained; resin gels at room temperature)
- For standard test specimens: pour into 25 mL crucibles or ASTM mold templates
- Work quickly (pot life at 80°C ~15–20 minutes before gelation begins)

9. Cure Schedule (Two-Stage):

Stage 1 — Room Temperature Gelation (24–48 hours):

- Allow filled molds to cool slowly to room temperature over 2–3 hours (prevents cracking)
- Cure at 23–25°C for 24–48 hours (network formation via esterification)
- Resin becomes rigid but still slightly tacky

Stage 2 — Heat Cure (Post-cure):

- Transfer molded parts to oven
- Ramp temperature: 50°C → 80°C → 120°C over 12 hours (slow ramp reduces stress)
- Hold at 120°C for 4 hours (completes primary esterification)
- Cool in oven to <50°C before removal
- Optionally: Flash cure at 150°C for 30 minutes (strengthens dynamic bonds; not essential)

10. Post-Processing:

- Demold specimens from molds
- Sand excess material with 220–400 grit sandpaper if needed

- Store samples in dry conditions at room temperature in sealed containers

Procedure B: Solvent-Assisted Synthesis (Hempoxies 56 Enhanced)

For improved homogeneity and reproducibility (especially with reinforcement fibers):

1. Preparation:

- Weigh EHSO (100 g), FGE (8.9 g), anhydrous ethanol (10 g total)
- Pre-heat in reaction vessel to 70°C

2. Resin Blend:

- Mix EHSO + FGE at 70°C for 2 min (ethanol already present from subsequent step)

3. Catalyst Dissolution (Improved):

- Dissolve $\text{Zn}(\text{OAc})_2 \cdot 2\text{H}_2\text{O}$ (1.0 g) in ~2 mL anhydrous ethanol in separate flask
- Gently warm to 40–50°C to enhance solubility
- Stir until fully dissolved (clear solution)

4. Addition to Resin:

- Add catalyst solution dropwise to EHSO+FGE blend at 70°C
- Stir at 400 rpm for 2 minutes

5. Citric Acid Addition (Ethanol-Slurried):

- Separately, suspend citric acid (36.5 g) in anhydrous ethanol (15 mL)
- Stir to create fine slurry (not fully dissolved)
- Slowly add slurry to main vessel at 70°C over 5–8 minutes while stirring

6. Mixing & Gelation:

- Increase stir rate to 600 rpm after slurry addition
- Continue 8–10 minutes at 70°C
- As ethanol evaporates, mixture thickens

7. Ethanol Removal (Optional):

- To accelerate ethanol evaporation: Heat to 90–100°C under low vacuum for 10–15 minutes

- Monitor consistency; stop when mixture reaches desired viscosity (pourable but not fluid)

8. Casting & Cure:

- Proceed with degassing and mold casting as in Procedure A
- Use identical cure schedule

Monitoring Reaction Progress:

- **Gel Time:** At room temperature ($\sim 25^{\circ}\text{C}$), mixture sets to gel (~ 1 mm penetrometer resistance) in 24–36 hours
- **Tack-Free Time:** ~ 48 hours at room temperature
- **Shore D Hardness:** Progresses from ~ 55 (48 hr RT) to ~ 78 – 82 (120°C post-cure)
- **FT-IR Monitoring:**
 - Epoxy C–O peak at 840 – 860 cm^{-1} diminishes over time
 - Ester C=O peak at 1735 cm^{-1} increases
 - By 120°C post-cure: epoxy peak nearly absent, ester peak strong

IV. STAGE 3: REINFORCEMENT INTEGRATION

Hierarchical Carbon Morphology Incorporation

The Hempoxies platform can be reinforced with various carbon forms to tailor stiffness and strength. All reinforcements are co-processed during the matrix synthesis stage.

Reinforcement Options:

Morphology	Volume Fraction	Aspect Ratio	Application	Density (g/cm^3)
PAN-based Carbon Fiber (CF)	20–40%	~ 80 – 150	High-strength load-bearing	1.60
Native Hemp Bast Fiber	10–30%	~ 30 – 100	Lightweight bio-composite	1.48
Biochar	5–15%	~ 1 – 5	Thermal conductivity,	1.2–1.3

(thermolyzed hemp)			damping	
Activated Carbon	5–10%	~1–3	Electrical conductivity, sorption	1.3–1.5
Carbonized Hemp Fiber	10–25%	~20–60	Hybrid stiffness/weight	1.50
Graphene Nanosheets (G)	0.5–3%	>1000 (lateral)	Ultra-high modulus	2.0
MXenes ($\text{Ti}_3\text{C}_2\text{T}_x$)	0.5–2%	>500 (lateral)	Electrical/thermal enhancement	4.1

Hemp-Derived Carbon Morphologies (Preparation):

Biochar from Hemp Hurds:

1. Dry hemp shives (woody core) at 105°C overnight
2. Pyrolyze in muffle furnace at 450–600°C for 2–4 hours under inert atmosphere (N_2 flow)
3. Cool to room temperature in furnace
4. Grind to <100 mesh powder
5. Store in sealed container

Activated Carbon (from Biochar):

1. Treat biochar with KOH (mass ratio 1:1) in ethanol slurry
2. Dry at 105°C
3. Activate in muffle furnace at 700–850°C for 1–2 hours (N_2)
4. Cool, wash with dilute HCl, then distilled water
5. Dry at 105°C and store

Carbonized Hemp Fiber:

1. Demineralize raw hemp fiber in dilute HCl, then distilled water
2. Dry at 105°C
3. Pyrolyze at 800–1000°C for 1–2 hours (N_2)

4. Cool and bundle into fiber form

Reinforced Composite Synthesis:

Procedure (20 wt% PAN-CF + 5 wt% Biochar Example):

1. Fiber Pre-treatment:

- Use chopped PAN-CF (3–6 mm length) at 20 wt% of total resin
- Pre-coat lightly with ~0.1 wt% silane coupling agent (γ -methacryloxypropyltrimethoxysilane, A-187) in ethanol
- Dry coated fibers at 80°C for 1 hour
- Add pre-treated CF to mold cavity

2. Biochar Dispersion:

- In small portion of EHSO (10 wt% of total), disperse biochar (5 wt% of final composite) via sonication for 5 minutes
- Use probe sonicator at 50–60% amplitude
- This pre-dispersed slurry improves homogeneity

3. Resin Synthesis (Modified):

- Prepare base EHSO+FGE+Zn(OAc)₂+Citric acid matrix as in Stage 2
- Substitute 10 g of EHSO with biochar-loaded EHSO from step 2
- Mix thoroughly to distribute particles

4. Fiber Wetting:

- Pour resin mixture onto chopped CF in mold cavity
- Work mixture into fiber bed with spatula (3–5 minutes) to ensure fiber wetting
- Remove air pockets by manual vibration or centrifugation

5. Cure Schedule:


- Use identical cure protocol as Stage 2 (RT 24–48 hr, then 120°C post-cure)

V. TOPOLOGY FREEZING TEMPERATURE (T_v) & DYNAMIC

PROPERTIES

Theoretical Basis

Above T_v (~150–160°C for Hempoxies), associative transesterification activates:



This enables:

- **Healing:** Severed bonds reform at elevated temperature
- **Reshaping:** Parts can be reheated and compression-molded into new shapes
- **Recycling:** Fully recyclable via re-heating and re-molding

Measuring T_v :

Dynamic Mechanical Analysis (DMA):

- Plot storage modulus (E') vs. temperature
- T_v is where E' begins a sharp decline (typically over 50–100°C temperature window)
- For Hempoxies: E' peak around 150–160°C

Rheology (Oscillatory):

- Measure complex viscosity (η^*) and phase angle (δ) from 25°C → 200°C at 1 Hz
- T_v = temperature where $\tan(\delta) = 1$ ($G' = G''$)

VI. PROJECTED PROPERTIES (TRL 1–2)

Mechanical Properties (Unfilled Matrix)

Property	Unit	Target Value	Notes
Tensile Strength	MPa	35–50	Dynamic network; lower than thermosets
Tensile Modulus	GPa	0.8–1.2	Bio-derived matrix; moderate stiffness
Elongation @ Break	%	2–5	Brittle thermosetting behavior

Flexural Strength	MPa	45–60	—
Flexural Modulus	GPa	1.0–1.5	—
Compressive Strength	MPa	80–120	Matrix-dominated property

Reinforced Composites (20 wt% PAN-CF)

Property	Unit	Projected Value
Tensile Strength	MPa	180–250
Tensile Modulus	GPa	8–12
Density	g/cm ³	1.25–1.35

Thermal Properties

Property	Unit	Target Value
Glass Transition (T _g , DMA)	°C	~110–130
Topology Freezing (T _v)	°C	150–160
Decomposition Onset (TGA, 5% loss)	°C	>280
Coefficient of Thermal Expansion (CTE)	ppm/K	40–60
Thermal Conductivity	W/m·K	0.15–0.25

Environmental Properties

Property	Notes
Carbon Footprint	Projected net-negative via 100% bio-derived feedstocks
Recyclability	Infinite solid-state recycling via thermal reprocessing
Biodegradability	Slowly degradable under soil/aqueous conditions; not fully compostable

VII. CURE KINETICS & OPTIMIZATION

DSC (Differential Scanning Calorimetry) Analysis

Expected DSC thermogram (25–200°C scan, 10°C/min):

1. **30–70°C:** Broad exothermic peak (esterification of epoxy + citric acid carboxyls)
2. **70–120°C:** Secondary shoulders (continued esterification)
3. **150–170°C:** Small endothermic upturn (T_v transition; no major reaction)
4. **>170°C:** Flat baseline (no further reactivity)

Integration of Area 1 & 2: Total heat of reaction $\approx$ 200–350 J/g (varies with formulation)

Activation Energy (E_a)

For epoxy-carboxylic acid reaction:

- Estimated E_a $\approx$ 60–80 kJ/mol (transesterification pathway)
- Isothermal cure @ 120°C follows approximately first-order kinetics for early stages

VIII. TROUBLESHOOTING & COMMON ISSUES

Issue	Cause	Solution
Unreacted white residue	Citric acid precipitation; incomplete dissolution	Increase ethanol % or pre-dissolve citric acid in warm ethanol before addition
Brittleness/cracking	Cure too fast or incomplete mixing	Slow cure ramp (50°C/hr); increase FGE diluent to 10–12 wt%
Poor fiber wetting	High viscosity prevents fiber penetration	Increase FGE to 10–12 wt%; warm resin to 70°C before pouring

Yellow/brown discoloration	Oxidation or excessive heating	Store EHSO under nitrogen; avoid >150°C during synthesis
Low tensile strength	Incomplete crosslinking	Extend post-cure to 120°C × 6–8 hours; check catalyst dispersion
Poor recycling (doesn't reshape)	Incomplete network formation	Ensure 120°C post-cure; confirm T_v around 150–160°C via DMA

IX. SAFETY & DISPOSAL

Hazardous Materials Handling:

- **Hydrogen Peroxide (H_2O_2):** Oxidizer; causes burns. Wear nitrile gloves, eye protection, and work in fume hood.
- **Formic Acid:** Corrosive; causes severe burns. Use in fume hood; avoid skin contact.
- **Performic Acid:** Extremely corrosive and unstable. Generate in situ; never store. Immediate addition to oil is required.
- **Zinc Acetate:** Low toxicity but respiratory irritant in powder form; use dust mask during handling.
- **Furfuryl Glycidyl Ether:** Skin irritant; potential sensitizer. Use nitrile gloves and avoid prolonged contact.

Waste Disposal:

- **Spent Ion Exchange Resin:** Rinse with water; dispose as non-hazardous solid waste or regenerate if feasible.
- **Aqueous Ethanol Washings (from workup):** Evaporate ethanol; neutralize remaining aqueous solution with NaOH; dispose as non-hazardous aqueous waste.
- **Cured Resin Scraps:** Can be thermally recycled (reheated to T_v , reprocessed) or landfilled (non-toxic).
- **Uncured Resin:** Harden by adding excess cold water (hydrolyzes epoxy); dispose as solid waste.

Personal Protective Equipment (PPE):

- Chemical-resistant nitrile gloves (double-gloving recommended)

- Safety glasses or full face shield
 - Lab coat or protective apron
 - Closed-toe shoes with chemical-resistant sole
 - Respiratory protection (N95 or equivalent) when handling powdered citric acid or biochar
-

X. NEXT STEPS FOR VALIDATION (TRL 2→3 PATHWAY)

Critical Experiments:

1. **FTIR/NMR Spectroscopy:** Confirm epoxy consumption and ester formation
2. **Dynamic Mechanical Analysis (DMA):** Measure T_g, T_v, and tan(δ) profile
3. **Tensile Testing (ASTM D638):** Validate projected strength of 35–50 MPa for neat resin
4. **Recycling Trials:** Thermal reprocessing of molded samples; measure property retention
5. **Environmental Footprint LCA:** Quantify net carbon sequestration vs. petroleum thermosets
6. **Fiber Composite Validation:** Test carbon-fiber-reinforced samples; verify 180+ MPa tensile strength

Long-Term Objectives:

- Pilot-scale EHSO production (kg quantities)
 - Building component prototyping (roof tiles, panels, insulation boards)
 - Industrial partnership with composite manufacturers
 - Regulatory pathway for construction material standards (ASTM, ISO)
-

References & Resources

- Landry, M.-S.S. (2026). Hemproxies v.17.2: A bio-derived structural vitrimer platform. *Zenodo*. DOI: 10.5281/zenodo.19877276

- Landry, M.-S.S. (2026). Hempoxies 56: TRL 1–2 research hypothesis. *Zenodo*. DOI: 10.5281/zenodo.20457469
- Hemp fiber composites literature (see ZILA BioWorks collaboration notes)
- Vitrimer chemistry reviews (Liebault et al., Montarnal et al.)

Open Science GitHub Repository: <https://github.com/MLSpyShop/Hempoxies>

Document Status: Open-source research framework (CC-BY 4.0)

Last Updated: September 2026

Disclaimer: This document represents theoretical TRL 1–2 research with projected (not validated) performance targets. All synthesis procedures are laboratory-scale hypothetical protocols. Practical implementation requires rigorous experimental validation, safety testing, and regulatory approval.